







## CANNON. Johnson Outdoors Marine Electronics, Inc. 121 Power Drive Mankato. MN 56001 cannondownriggers.com Part #3395373 TO ASSEMBLE LOCK: Insert lock body into rear lock hole in base. Partially thread on jam nut to lock body, Install lock cam, lock washer and nut on to the end

of the lock body. Fully tighten jam nut to base, then tighten cam nut to the cam and lock washer.











